

# MENUS

## Test

### Status

Several windows of status information

### Start/Stop

Starts & pauses run

### Save

Finishes run & saves last cycle

### Clear

Finishes run & discards last cycle

### Purge

Starts pump. Can be stopped by pushing MENU key

### Lock

Locks keypad. To release, see manual

### Sleep

Minimizes power use

### Print

Prints data of current cycle

### Com

Downloads data of current (incomplete) test cycle

## Data

### Read

Displays data of past records

### Print

Prints data of past records

### Com

Downloads data of current and past runs

### Summary

Prints summary of current or past runs, including bar chart

### Free

Displays number of free records in memory

### Delete

Delete a single run in memory

### Renumber

Renumber runs, after deleting one or more

### Erase

Erase all data in memory

## Setup

### Protocol

Choose one of nine different preset protocols

### Cycle

Set cycle time

### Recycle

Set number of cycles in run

### Mode

Choose counting mode

### Thoron

Enable thoron printout

### Pump

Set pump control mode

### Tone

Change tone setting

### Format

Control length of printout

### Units

Set radon & temperature units

### Savuser

Save your individual setup

### Clock

Set clock

### Review

Print, and display, a review of the RAD7 setup

## Note

Pushing the MENU key will always display '>Test' prompt.

Arrow keys move between selections.

The ENTER key accepts and implements selection.